

WIRING / CONNECTION GUIDE

(20-PIN) SECONDARY CONNECTOR

	(+) Foot Brake	Black	IN	A1	IN	Yellow	(+) BYPASS IGNITION	
750mA	(-) Parking lights	Pink	OUT		OUT	Purple	(-) LOCK	750mA
750mA	(-) Trunk Release/AUX	Yellow/Black	OUT		OUT	Purple/White	(-) UNLOCK	750mA
	(-) Hand Brake	Brown/White	IN		OUT	Green	(-) IGNITION	750mA
	(-) Hood/Door	Pink/Black	IN		OUT	White	(-) START	750mA
	Bypass config.	Purple/Yellow	⊖		OUT	Orange	(-) DISARM	750mA
	Bypass config.	Green/White	⊖		OUT	Orange/Black	(-) HORN/SIREN	2 Amp
	Bypass config.	Green/Red	⊖		OUT	Dk.Blue	(-) GWR/PROGRAMMABLE	750mA
	Bypass config.	White/Black	OUT	A20	IN	Red/Blue	BYPASS CONFIG.	
	Bypass config.	Lt.Blue	⊖		⊖	Lt.Blue/Black	BYPASS CONFIG.	



750 mA MAXIMUM OUTPUT. DO NOT EXCEED THE MAXIMUM CURRENT OR PERMANENT DAMAGE TO THE MODULE WILL OCCUR THAT WILL NOT BE COVERED UNDER WARRANTY.

(6-PIN) POWER CONNECTOR

Ground	Black	IN	E1	OUT	White	(+) PARKLIGHTS/IGN2/ACC/START PROGRAMMABLE OUTPUT (FUNCTION 2 & 31)
(+) Ignition	Pink	OUT		OUT	Orange	(+) ACC / IGN2 PROGRAMMABLE OUTPUT (FUNCTION 2 & 31)
(+) Starter	Yellow	OUT	E6	IN	Red	(+) 12V

(3-PIN) SHOCK SENSOR

(2-PIN) Valet/
Programming Button



(6-PIN) BYPASS RELAY

(5-PIN) CAN-BUS

(4-PIN) DATA-LINK ANTENNA

REMOTE STARTER PROGRAMMING LED
BYPASS PROGRAMMING BUTTON

(4-PIN) RS-232 DATA-LINK & FLASH-LINK UPDATER PORT

(4-PIN) ANTENNA













DOWNLOAD THE
SPECIFIC VEHICLE
INSTALLATION GUIDE AT:
WWW.FORTIN.CA

PROGRAMMING REMOTE TRANSMITTER(S)










The system can learn up to a maximum of 4 transmitters. Any transmitters can be stored in more than 1 memory slot. When a 5th transmitter is learned the 1st remote is erased (FIFO).



*Valet switch sold separately

STEP 1	STEP 2	STEP 3	STEP 4	STEP 5	STEP 6
	 <p>Turn the Ignition OFF.</p>	 <p>Turn the Ignition ON.</p>	 <p>The LED will turn ON.</p>		
<p>Turn the Ignition ON.</p>	<p>WITH VALET SWITCH*</p>  <p>Press and hold the valet switch* until the parking lights turn ON, the horn/siren will chirp.</p>	<p>Press and release the valet switch* five time. The parking lights will flash and the horn/siren will chirp each time to confirm.</p> <p>x5</p>	<p>Press and release the brake pedal four times.</p> <p>x4</p>	<p>Press and release the brake pedal once.</p> <p>x1</p>	<p>On each Transmitter Press and HOLD the  for 12 SECONDS approximately and WAIT for the Blue LED to TURN OFF then back ON SOLID then release .</p> <p>The LED will stop flashing for a second confirming programming.</p>
				<p>The LED will flash rapidly.</p>	 <p>Turn the Ignition OFF to exit programming.</p>

ERASES ALL REMOTES THAT HAVE BEEN PROGRAMMED AND RESETS ALL FUNCTIONS BACK TO DEFAULT.


	STEP 1	STEP 2	STEP 3	STEP 4	STEP 5	STEP 6
<p>Disarm the system (The antenna led must not be flashing, see enter/exit valet mode p.6).</p>	 <p>Turn the Ignition ON.</p> <p>Within 5 sec. →</p>	<p>OR</p>   <p>Press and hold the valet switch* or the antenna button until the Parking lights turn ON, the horn/siren will chirp.</p>	<p>OR</p>   <p>Press and release the valet switch* or the antenna button 23 TIMES.</p>	 <p>x1</p> <p>Press and release the brake pedal once.</p>	<p>OR</p>   <p>Press and hold the valet switch* or the antenna button for 5 seconds. The Parking lights will flash to confirm.</p>	 <p>Turn the Ignition OFF to exit programming. The Parking lights will flash 4 times.</p>

FUNCTION PROGRAMMING

TO PROGRAM THE REMOTE-STARTER FUNCTION:



Connect the EVO-ONE to the FLASH LINK UPDATER* and navigate in the Flash-Link Manager*.



*Parts required (not included)

MANUAL TRANSMISSION SEQUENCE ⚠ FOR COMPATIBLE VEHICLES ONLY

STEP 1	STEP 2	STEP 3	STEP 4	STEP 5	STEP 6	STEP 7
<p>Make sure that all doors are closed and the transmission is in the NEUTRAL position.</p>	<p>Press the brake</p>	<p>While the engine is running. Engage the parking brake.</p>	<p>Release the brake pedal</p>	<p>Push the START button (3sec.). The Parking lights will flash once and then remain on.</p>	<p>Remove the key from the ignition barrel. The vehicle will remain running with the Remote-Starter.</p>	<p>Exit the vehicle and close all of the doors. The Remote-Starter will stop running once all the doors are closed.</p>

WILL DISABLE MANUAL TRANSMISSION SEQUENCE








STANDARD

- Open any door(s)

- Open the hood
- Disengage the parking brake


Note : If the Parking lights flash 3 times when Remote-Starting, Ready Mode is not enabled.


DISARM / ENTER / EXIT VALET MODE

			STEP 1		STEP 2		
to disarm the system		System armed : DEL flash			OR		
to enter and exit valet mode		System disarmed : LED is OFF	Insert the key and turn it to the ignition (ON/RUN) position.		3x 	3x 	System disarmed : LED is OFF
					Within 10 seconds press and release the Valet switch or the antenna button 3 TIMES.		
							System disarmed and in valet mode : LED is ON.




REMOTE START DIAGNOSTICS

	Parking Lights flashes (before starting) :
3x	Ready mode disabled
4x	Valet mode activated (The LED is on)
5x	Hood open

	Parking Lights flashes (after Shutdown) :
1x	Normal stop (Brake, Park Brake)
3x	Runtime expired or shut down by transmitter
4x	No tachometer signal
5x	Hood open
6x	Over crank threshold (8 seconds)

ALARM DIAGNOSTICS

	Parking Lights flashes (after disarm) :
3x	Door open – zone 3
4x	Shock sensor – zone 4
5x	Hood open – zone 5
6x	Trunk open – zone 6

WARNING

NOTICE The manufacturer will accept no responsibility for any electrical damage resulting from improper installation of the product, including either damage to the vehicle itself or to the remote-starter module. This module must be installed by a certified technician including all of the supplied safety devices. Please note that this guide has been written for trained professional technicians, a certain level of skills and knowledge is therefore assumed. Please review the Installation Guide carefully before beginning any work.

WARNING By default this system is setup for vehicles with a manual transmission. For vehicles with an automatic transmission the safety wire loop on the main unit must be cut. Before proceeding to the installation, make sure that the vehicle does not attempt to start when the vehicle is in the "drive" or "reverse" position. If an automatic transmission vehicle starts when the transmission is in gear, ensure that the safety wire loop on the unit is not cut. Once the safety wire loop is cut, the system is considered an automatic transmission remote-starter indefinitely. Once a loop is cut all warranties, guarantees, and liability is immediately void if the unit is install on a manual transmission vehicle. Neither the manufacturer or distributor of this module is responsible of damages of any kind indirectly or directly caused by this module, except for the replacement of this module in case of manufacturing defects. This module must be install by qualified technician. This instruction guide may change without notice. To download the installation guide, user guide, or the latest quick installation guide, visit: WWW.FORTIN.CA

Technical support: TEL: 514-255-4357 / 1-877-336-7797

Copyright © 2014-2019, FORTIN AUTO RADIO INC ALL RIGHTS RESERVED MADE IN CANADA

REV.:20200619