

PATS TOYOTA

INSTALLATION

- 1- Install the remote starter and test by placing the original key in the barrel.
- 2- Remove the covers surrounding the ignition barrel.
- 3- Install the loop antenna around lighting ring in the barrel.
- 4- Secure the wire with tie-wrap.
- 5- Connect the RED wire to 12V constant and the BLACK wire to “ out when running “. **Keep the BLACK wire bare** for programming procedure.
- 6- Program the Pats Toyota.

PROGRAMMATION

Before starting the programming procedure, be sure to get 1 functional key of the vehicle, bare the BLEU (key sense) wire from the barrel (see illustration in the back). Each step must be completed in the indicated delay, otherwise the Pats Toyota will not be programmed therefore it would be necessary to restart the procedure.

- 1- **Insert the key** into the ignition barrel. (Do not turn)
- 2- Within 15 seconds, **depress and release the acceleration pedal 4 times.**
- 3- Within 20 seconds, **depress and release the brake pedal 5 times.**
- 4- **Remove the key** from ignition barrel.
- 5- Within 10 seconds,
1° Connect the BLACK wire from the Pats Toyota to GROUND
2° Connect the BLEU (key sense) wire from the barrel to GROUND
depress and release the acceleration pedal 1 times.
- 6- **After 60 seconds, disconnect the ground** from the BLEU wire from barrel **and** the BLACK wire from the Pats Toyota.
Note: The BLEU and the BLACK wires must be not connecting together after the programmation.
- 7- **End**

Patent pending Canada: 2,419,697 USA: 60/449.414