


# GM DATA ALL DATA LINK

All GM data controlled vehicles. Control of doorlock functions, OEM Security, Passlock and PK3 (plus functions as listed below). Interface module self-adjusts to various vehicle platforms (see application chart).

## GMDAAF



### PROGRAMMING SEQUENCE :

- Once the connections are done, connect the connector 2 (White). Locate and press the programming switch while inserting the connector 1 (Black) of the GMDAAF module. The LED status indicator will illuminate to indicate you are in programming mode. Keep the programming button pressed while turning the ignition to the "ON" position. Release the programming switch once the LED status indicator flashes rapidly.
- Start the engine (utiling the vehicle key). The LED status indicator will turn off to indicate the module has been programmed for either PK3 or Passlock (and control of additional features where applicable). Turn the key to the "OFF" position. The module is now ready for use.

**Note:** The manufacturer/distributor is not responsible for any damages which may directly or indirectly result from the installation of this module. The manufacturer/distributor is limited to the repair or replacement of this module in the case of manufacturing defects.

Manufactured under US patent No.:  
5,719,551 6,011,460 B1  
6,243,004 B1 6,249,216 B1  
6,275,147 B1 6,529,124 B2  
6,696,927 B2 6,756,885 B1  
6,756,886 B2 6,771,167 B1  
Canadian patent No.:  
2,320,248 2,415,023  
European patent No.:  
1,053,128

**Order Part Number: GMDAAF**

Version : 1.4

Revision : Sept 04 2004

Made in Canada

### GM DATA ALL - DATA LINK

Vehicle	Years							PK3 or Passlock Bypass	Doorlock Control	Trunk Release Control	OEM Alarm Control	Heated Seat Control
	98	99	00	01	02	03	04					
Bravada	X	X	X	.	.	.	.	X	.	.	.	?
Envoy	X	X	X	.	.	.	.	X	.	.	.	?
Trailblazer	X	X	X	.	.	.	.	X	.	.	.	?
Avalanche	X	X	X	X	.	.	.	X	.	.	.	.
Escalade	X	X	X	X	.	.	.	X	.	.	.	.
C/K Pick Up	X	X	X	X	.	.	.	X	.	.	.	.
Silverado	X	X	X	X	.	.	.	X	.	.	.	.
Sierra	X	X	X	X	.	.	.	X	.	.	.	.
Suburban	X	X	X	X	.	.	.	X	.	.	.	.
Tahoe	X	X	X	X	.	.	.	X	.	.	.	.
Yukon (all)	X	X	X	X	.	.	.	X	.	.	.	.
Hummer	X	X	X	X	.	.	.	X	.	.	.	.
Aurora	.	.	?	.	.	.	.	.	.	.	.	↑ Heated Seat will turn ON at low power only if the engine temp is below 0°C when it started.
SRX	.	.	.	.	.	.	.	.	.	.	.	
CTS	.	.	.	.	.	.	.	.	.	.	.	
Deville	.	.	?	.	.	.	.	.	.	.	.	
Le Sabre	.	.	.	.	.	.	.	.	.	.	.	
Bonneville	.	.	.	.	.	.	.	.	.	.	.	
Park Avenue	.	.	?	.	.	.	?	.	?	?	?	
SLS	.	.	?	.	.	.	.	.	.	.	.	
STS	.	.	?	.	.	.	.	.	.	.	.	
Alero	.	.	.	.	.	.	.	.	.	.	.	
Astro	.	.	.	.	.	.	.	.	.	.	.	NON COMPATIBLE
Blazer	.	.	.	.	.	.	.	.	.	.	.	
Cavalier	.	.	.	.	.	.	.	.	.	.	.	
Express Van	.	.	.	.	.	.	.	.	.	.	.	
Grand Am	.	.	.	.	.	.	.	.	.	.	.	
Impala	.	.	.	.	.	.	.	.	.	.	.	
Intrigue	.	.	.	.	.	.	.	.	.	.	.	
Monte Carlo	.	.	.	.	.	.	.	.	.	.	.	
S-10	.	.	.	.	.	.	.	.	.	.	.	
Safari	.	.	.	.	.	.	.	.	.	.	.	
Saturn Série S	.	.	.	.	.	.	.	.	.	.	.	Option : Connect the WHITE wire to ignition. This is a mandatory connection for vehicles in this category.
Savana	.	.	.	.	.	.	.	.	.	.	.	
Sonoma	.	.	.	.	.	.	.	.	.	.	.	
Sunfire	.	.	.	.	.	.	.	.	.	.	.	
Astek	.	.	.	.	.	.	.	.	.	.	.	
Grand Prix	.	.	.	.	.	.	.	.	.	.	.	
Montana	.	.	.	.	.	.	.	.	.	.	.	
Rendez-vous	.	.	.	.	.	.	.	.	.	.	.	
Silhouette	.	.	.	.	.	.	.	.	.	.	.	
Venture	.	.	.	.	.	.	.	.	.	.	.	

X-- TESTED and functional unique fonction.

.

?