## Transponder Bypass, Factory Alarm and Door-Lock control for all Chrysler vehicle

## PROGRAMMATION : DATA portion

One the connections are done.

Connect the connectors 2 and 3, following with connector 1. Turn the key ON, wait a few secondes, the horn or key buzzer will be heard 3 times. Turn the key OFF. The DATA portion of the module is now ready to work.

## **PROGRAMMATION : TRANSPONDER portion**

The programming procedure of Transponder required 2 fonctional keys. Keep the keys separate from one another while performing the programming. Each step must be completed within the indicated delay, otherwise the CHRDAA will not program properly.

1- Insert the first fonctional vehicle key into the ignition cylinder and turn ignition to the ON position. Maintain ignition in the ON position for 8 to 10 seconds.

2- Turn the key to the OFF position and remove the first key.

3- Within 10 seconds of turning ignition to the OFF position, insert the second functional key and turn ignition to the ON position. Maintain ignition in the ON position for 8 to 10 second

4- Depending on the vehicle model, the vehicle security light will begin to flash or an audible tone will sound to indicate you have accessed the vehicle programming mode.
 5- Turn the key to the OFF position and remove the second key.
 6- Within 30 seconds of turning the key OFF position, place the Transponder of CHRDAA module (show on the label) close and toward the front of ignition barrel, with the help of a jumper

power up **12Volts to the vehicle ignition**. Approximately 8 to 10 seconds afterwards the security light will stop flashing indicating the CHRDAA has successfully been programmed. Disconnect 12V from ignition jumper. Note: you can also temporarily replace the internal circutry of one of the vehicle Key-remote by the CHRDAA for programming than you will not have to jump 12V ignition.

7- Remotely start the vehicle. The engine will run if the programming procedure was successfully completed. If the programming procedure was unsuccessfully completed, the engine will not run and the vehicle security light flash. In such a case repeat the above procedure beginning with step 1.

\*\* NOTE : Do not attempt to remotely start the vehicle more than 4 consecutive times with a non functional CHRDAA module.

## CHRYSLER DATA ALL 2004

Note: Neither the manufacturer or distributor of this module is considered to be responsible of damages of any kind indirectly or directly caused by this module, except for the replacement of this module in case of manufacturing defects.

с		Note: You cal	n program the transponder only
conn			
F	I I WHITE	N.C.	
n 2	PINK/BLACK	Output analog 3 (see Note 2)	
conn	PINK	Output analog 2 (see Note 2)	
F	GREEN	N.C.	
	BLUE	(-) Input GndOut of remote starter	(
	ORANGE/BLACK	Output DATA	
	ORANGE	(-) Input disarm and unlock	Bemote
	PURPLE/WHITE	(-) Input arm and lock	
conn	PURPLE	(-) Input trunk	Starter
Ö	YELLOW/BLACK	(-) Input driver sliding door	
	YELLOW	(-) Input passenger sliding door	
	RED	(+) 12V Battery	
	BLACK	(-) Ground	
L			
			1 2 2 4 5 6 7 9



2 to 5 turns of loop is

required

Clé/key

Diagnostic plug View from the front Located below dash

Note 2. Door lock and factory

Г

	Fonctions							Wire Color			
Vehicle	ehicle Year		Transponder Bypass	Door-lock Trunk og control contro	Trunk open control	<sup>n</sup> Fartory alarm control	Sliding door control	With OEM Security	Without OEM Secur		
	02	03	04	05					1	Wire : Analog 3	Wire : Anal
Town & Country			٠	•	· · ·	V	V	$\checkmark$	V	Violet / Blue	Violet / G
Caravan			٠	•	V	<ul> <li>✓</li> </ul>	V	$\checkmark$	<ul> <li>✓</li> </ul>	Violet / Blue	Violet / G
Grand caravan			٠	•	V	V	<ul> <li>✓</li> </ul>	$\checkmark$	<ul> <li>✓</li> </ul>	Violet / Blue	Violet / E
	02	03	04	05							
Pacifica		٠	٠		✓	V	V	$\checkmark$		None	None
	02	03	04	05							